

COSZ-2A251-A 1960 Thunderbird Power Brake Spacer Kit

Parts List - included in kit:

1 Push Rod - COSS-2A022-A - Not included - 2 wave washers, 2 nylon bushings at pedal end.

1 COSS-2A248-A Spacer Bracket.

4 5/16" nut - 33923-S7.

4 Lockwasher - 34806-S7 to mount cylinder to bracket.

NOT included in kit:

1 Lever with Clevis Pin & cotter pin, Lever Pin, 2 nylon bushings and nut.

1 End Plate and Boot - 5 lock washers and nuts.

